SECTION SB

SEAT BELTS

CONTENTS

PRECAUTIONS 2
Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER” 2
Precautions for Seat Belt Service 2
AFTER A COLLISION 2
SEAT BELTS 3
System Description 3
SEAT BELT WARNING LAMP 3
Removal and Installation of Front Seat Belt 3
REMOVAL OF SEAT BELT RETRACTOR 3
INSTALLATION OF SEAT BELT RETRACTOR.... 3
REMOVAL OF SEAT BELT BUCKLE 4
INSTALLATION OF SEAT BELT BUCKLE 4
Removal and Installation of Rear Seat Belt 4
REMOVAL OF LH/RH SEAT BELT 4
INSTALLATION OF LH/RH SEAT BELT 4
REMOVAL OF CENTER SEAT BELT 5
INSTALLATION OF CENTER SEAT BELT 5
Seat Belt Inspection 6
AFTER A COLLISION 6
PRELIMINARY CHECKS 6
SEAT BELT RETRACTOR ON-VEHICLE CHECK 7
SEAT BELT RETRACTOR OFF-VEHICLE CHECK 8
TOP TETHER STRAP CHILD RESTRAINT 9
Removal and Installation 9
REMOVAL 9
INSTALLATION 9

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

AHS000PQ

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- **To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.**
- **Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.**
- **Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.**

Precautions for Seat Belt Service

AHS000RE

CAUTION:

- **Before removing the seat belt pre-tensioner assembly, turn the ignition switch off, disconnect the both battery cables and wait at least 3 minutes.**
- **Do not use electrical test equipment for seat belt pre-tensioner connector.**
- **After replacing or reinstalling seat belt pre-tensioner assembly, or reconnecting front seat belt pre-tensioner connector, check the system function. Refer to SRS-13, "SRS Operation Check" .**
- **Do not use disassembled buckle or seat belt assembly.**
- **Replace anchor bolts if they are deformed or worn out.**
- **Never oil tongue and buckle.**
- **If any component of seat belt assembly is questionable, do not repair. Replace the whole seat belt assembly.**
- **If webbing is cut, frayed, or damaged, replace seat belt assembly.**
- **When replacing seat belt assembly, use a genuine NISSAN seat belt assembly.**

AFTER A COLLISION

WARNING:

Inspect all seat belt assemblies including retractors and attaching hardware after any collision. NISSAN recommends that all seat belt assemblies in use during a collision be replaced unless the collision was minor and the belts show no damage and continue to operate properly. Failure to do so could result in serious personal injury in an accident. Seat belt assemblies not in use during a collision should also be replaced if either damage or improper operation is noted. Seat belt pre-tensioner should be replaced even if the seat belts are not in use during a frontal collision in which the air bags are deployed.

Replace any seat belt assembly (including anchor bolts) if:

- The seat belt was in use at the time of a collision (except for minor collisions and the belts, retractors and buckles show no damage and continue to operate properly).
- The seat belt was damaged in an accident. (i.e. torn webbing, bent retractor or guide).
- The seat belt attaching point was damaged in an accident. Inspect the seat belt attaching area for damage or distortion and repair as necessary before installing a new seat belt assembly.
- Anchor bolts are deformed or worn out.
- The seat belt pre-tensioner should be replaced even if the seat belts are not in use during the collision in which the air bags are deployed.

SEAT BELTS

PFP:86884

System Description

AHS000RF

SEAT BELT WARNING LAMP

- Fasten driver's seat belt.
- The seat belt warning lamp should go out.
- If the seat belt warning lamp does not go out. Refer to DI-25, "Wiring Diagram — WARN —" .

Removal and Installation of Front Seat Belt

AHS000RG



CAUTION:

Before servicing SRS, turn the ignition switch off, disconnect both battery cables and wait at least 3 minutes.

REMOVAL OF SEAT BELT RETRACTOR

1. Remove adjust cover.
2. Remove shoulder anchor bolt.
3. Slide the floor anchor cover.
4. Remove floor anchor bolt.
5. Remove center pillar upper and lower garnish. Refer to EI-36, "Removal and Installation" .
6. Disconnect the seat belt pre-tensioner connector.

   CAUTION:

   - **For connecting/disconnecting seat belt pre-tensioner connector, insert thin screwdriver wrapped in tape into notch, lift lock and disconnect connector.**
   - **Connect connector with lock raised, and push lock into connector.**



7. Remove seat belt pre-tensioner retractor fixing screws to remove seat belt assembly.

INSTALLATION OF SEAT BELT RETRACTOR

CAUTION:

Before servicing SRS, turn the ignition switch off, disconnect both battery cables and wait at least 3 minutes.

Install in the reverse order of removal.

REMOVAL OF SEAT BELT BUCKLE

1. Remove front seat. Refer to SE-19, "REMOVAL" .
2. Remove screw, and remove seat cushion inner finisher. Refer to SE-17, "Component Parts Drawing" .
3. Remove anchor bolt to remove seat belt buckle.



INSTALLATION OF SEAT BELT BUCKLE

Install in the reverse order of removal.

Removal and Installation of Rear Seat Belt

AHS000RH



REMOVAL OF LH/RH SEAT BELT

1. Fold rear seat cushion up.
2. Remove luggage side lower finisher. Refer to EI-36, "Removal and Installation" .
3. Remove outer and inner anchor bolts.
4. Remove rear seat belt retractor.

INSTALLATION OF LH/RH SEAT BELT

Install in the reverse order of removal.

REMOVAL OF CENTER SEAT BELT

1. Fold rear seat cushion up.
2. Remove seat belt retractor cover.
3. Remove anchor bolts securing center seat belt retractor.
4. Remove rear seatback. Refer to SE-26, "SEATBACK" .
5. Remove rear seatback board.
6. Remove hog ring securing upper portion of rear seatback trim.
7. Remove rear seat belt guide.



8. Remove nuts securing rear seat belt.

   : 9.6 N·m (0.98 kg-m, 85 in-lb)



9. Remove rear center seat belt assembly from rear seatback.

INSTALLATION OF CENTER SEAT BELT

Install in the reverse order of removal.

Seat Belt Inspection

AHS000RI

AFTER A COLLISION

WARNING:

Inspect all seat belt assemblies including retractors and attaching hardware after any collision. NISSAN recommends that all seat belt assemblies in use during a collision be replaced unless the collision was minor and the belts show no damage and continue to operate properly. Failure to do so could result in serious personal injury in an accident. Seat belt assemblies not in use during a collision should also be replaced if either damage or improper operation is noted. Seat belt pre-tensioned should be replaced even if the seat belts are not in use during a frontal collision in which the air bags are deployed.

Replace any seat belt assembly (including anchor bolts) if:

- The seat belt was in use at the time of a collision (except for minor collisions and the belts, retractors and buckles show no damage and continue to operate properly).
- The seat belt was damaged in an accident (i.e. torn webbing, bent retractor or guide, etc).
- The seat belt attaching point was damaged in an accident. Inspect the seat belt attaching area for damage or distortion and repair as necessary before installing a new seat belt assembly.
- Anchor bolts are deformed or worn out.
- The seat belt pre-tensioner should be replaced even if the seat belts are not in use during the collision in which the air bags are deployed.

PRELIMINARY CHECKS

1. Check the seat belt warning lamp/chime for proper operation as follows:

a. Switch ignition ON. The seat belt warning lamp should illuminate. Also, the seat belt warning chime should sound for about seven seconds.

b. Fasten driver's seat belt. The seat belt warning lamp should go out and the chime (if sounding) should stop.

2. If the air bag warning lamp is blinking, conduct self-diagnosis using CONSULT-II, and air bag warning lamp. Refer to SRS-13, "SRS Operation Check" .

3. Check that the seat belt retractor, seat belt anchor and buckle bolts are securely attached.

4. Check the shoulder seat belt guide and shoulder belt height adjuster for front seats. Ensure guide swivels freely and that webbing lays flat and does not bind in guide. Ensure height adjuster operates properly and holds securely.

5. Check retractor operation:

a. Fully extend the seat belt webbing and check for twists, tears or other damage.

b. Allow the seat belt to retract. Ensure that webbing returns smoothly and completely into the retractor. If the seat belt does not return smoothly, wipe the inside of the loops with a clean paper cloth. Because dirt built up in the loops of the upper anchors can cause the seat belts to retract slowly.

c. Fasten the seat belt. Check the seat belt returns smoothly and completely to the retractor. If the webbing does not return smoothly, the cause may be an accumulation of dust or dirt. Use the “SEAT BELT TAPE SET” and perform the following steps.

   Inspect the front seat belt though-anchor

   1. Pull the seat belt out to a length of 500 mm (19.69 in) or more.
   2. Use a clip or other device to the fix the seat belt at the center pillar webbing opening.
   3. Pass a thin wire though the though-anchor webbing opening. Hold both ends of the wire and pull taut while moving it up and down several times along the webbing opening surface to move matter stuck there.
   4. Any dirt that can not be removed with the wire can be removed by cleaning the opening with a clean cloth.
   5. Apply tape at the point where the webbing contacts the though-anchor webbing opening.

      NOTE:

      Apply the tape so that there is no looseness or wrinkling.
   6. Remove the clip fixing the seat belt and check that the webbing returns smoothly.

6. Repeat steps above as necessary to check the other seat belts.

SEAT BELT RETRACTOR ON-VEHICLE CHECK

Emergency Locking Retractors (ELR) and Automatic Locking Retractors (ALR)

NOTE:

All seat belt retractors are of the Emergency Locking Retractors (ELR) type. In an emergency (sudden stop) the retractor will lock and prevent the webbing from extending any further. All 3-point type seat belt retractors except the driver's seat belt also have an Automatic Locking Retractors (ALR) mode. The ALR mode (also called child restraint mode) is used when installing child seats. The ALR mode is activated when the seat belt is fully extended. When the webbing is then retracted partially, the ALR mode automatically locks the seat belt in a specific position so the webbing cannot be extended any further. To cancel the ALR mode, allow the seat belt to fully wind back into the retractor.

Check the seat belt retractors using the following test(s) to determine if a retractor assembly is operating properly.

ELR Function Stationary Check

Grasp the shoulder webbing and pull forward quickly. The retractor should lock and prevent the belt from extending further.

ALR Function Stationary Check

1. Pull out entire length of seat belt from retractor until a click is heard.
2. Retract the webbing partially. A clicking noise should be heard as the webbing retracts indicating that the retractor is in the Automatic Locking Retractors (ALR) mode.
3. Grasp the seat belt and try to pull out the retractor. The webbing must lock and not extend any further. If NG, replace the retractor assembly.
4. Allow the entire length of the webbing to retract to cancel the automatic locking mode.

ELR Function Moving Check

WARNING:

Perform the following test in a safe, open area clear of other vehicles and obstructions (for example, a large, empty parking lot). Road surface must be paved and dry. DO NOT perform the following test on wet or gravel roads or on public streets and highways. This could result in an accident and serious personal injury. The driver and passenger must be prepared to brace themselves in the event the retractor does not lock.

1. Fasten driver's seat belt. Buckle a passenger into the seat for the belt that is to be tested.
2. Proceed to the designated safe area.
3. Drive the vehicle at approximately 16 km/h (10 MPH). Notify any passengers of a pending sudden stop and the driver and passenger must be prepared to brace themselves in the event the retractor does not lock, apply brakes firmly and make a very hard stop.

During stop, seat belts should lock and not be extended. If the seat belt retractor assembly does not lock, perform the retractor off-vehicle check.

SEAT BELT RETRACTOR OFF-VEHICLE CHECK

1. Remove the seat belt retractor assembly.
2. Slowly pull out webbing while tilting the retractor assembly forward from the mounted position without twisting the retractor assembly as shown in the illustration.



15 degrees or less tilt : Webbing can be pulled out.

35 degrees or more tilt : Webbing locks and cannot be pulled out.

If NG, replace the retractor assembly.

TOP TETHER STRAP CHILD RESTRAINT

PFP:88000

Removal and Installation

AHS000RJ

CAUTION:

Replace anchor bolts if they are deformed or worn out.

REMOVAL

1. Remove the luggage floor board (front). Refer to EI-36, "Removal and Installation" .
2. Remove the top tether strap child restraint.

   :24.0 N·m (2.4 kg-m, 18 ft-lb)



INSTALLATION

Install in the reverse order of removal.